Jetson Camera Documentation

Wednesday, March 6, 2019 12:11 PM

To read imx219 on i2c bus:


- 1. Connect camera to CSI port
- 2. Power on camera through GPIO pin 457 (CAM1-rst) ((Forums and manuals ask to turn on 461(CAM0-rst) but for some reason, it doesn't work))
 - a. sudo -I
 - b. echo 457 > /sys/class/gpio/export
 - c. echo out > /sys/class/gpio/gpio457/direction
 - d. echo 0 > /sys/class/gpio/gpio457/value
 - e. echo 1 > /sys/class/gpio/gpio457/value
- 3. To ensure step 1 is successful,
 - a. sudo i2cdetect -y -r 1 (if connected to CSI-CD of J90)
 - b. sudo i2cdetect -y -r 7 (if connected to CSI-EF of J90)
 - c. Output will look something like below. The 10 is the address of the camera.

0 1 2 3 4 5 6 7 8 9 a b c d e
00:
10: 10
20:
30:
40: UU
50: 50
60: 64
70.

Kernel source file changes:

The below is for a single camera set-up, connected to 2 lanes of the CSI-EF ports of the J90 board. The following changes should be made to the kernel source files between step 8, and step 9, in the Building Kernel TX2 document:

- Open 64_TX2/Linux_for_Tegra_tx2/sources/hardware/nvidia/platform/t18x/quill/kerneldts/tegra186-quill-p3310-1000-a00-00-base.dts
- $2. \quad \text{In the include commands, comment out the following commands:} \\$
 - a. #include <t18x-common-platforms/tegra186-quill-camera-modules.dtsi> should become //#include <t18x-common-platforms/tegra186-quill-camera-modules.dtsi>
 - b. #include <t18x-common-plugin-manager/tegra186-quill-camera-plugin-manager.dtsi> should become //#include <t18x-common-plugin-manager/tegra186-quill-camera-plugin-manager.dtsi>
- Rename tegra186-my-camera-config-a00_modules.dtsi to tegra186-my-camera-config-a00.dtsi, and copy it to 64_TX2/Linux_for_Tegra_tx2/sources/hardware/nvidia/platform/t18x/common/kerneldts/t18x-common-modules/
- Rename tegra186-my-camera-config-a00_platforms.dtsi to tegra186-my-camera-config-a00.dtsi, and copy it to 64_TX2/Linux_for_Tegra_tx2/sources/hardware/nvidia/platform/t18x/common/kerneldts/t18x-common-platforms/
- 5. Open 64_TX2/Linux_for_Tegra_tx2/sources/hardware/nvidia/platform/t18x/quill/kernel-dts/tegra186-quill-p3310-1000-c03-00-base.dts
 - a. Add #include <t18x-common-platforms/tegra186-my-camera-config-a00.dtsi>
- 6. Copy the modified imx219 driver file and mode tables file, 'imx219.c' and 'imx219_mode_tbls.h' to the folder: /64_TX2/Linux_for_Tegra_tx2/sources/kernel/kernel-4.4/drivers/media/i2c , replacing the original files
- 7. While running step 9.e (compile script) step, you will get a menuconfig UI, which looks like this:



- a. Press '/' button, and search 'IMX219'
- b. Press '1.' And then spacebar
- c. Press 'spacebar' until the module until the selection is a '*'
- d. Exit and save

This is necessary for enabling the IMX219 driver.

Primary References:

- 1. http://cospandesign.github.io/linux,tx2,kernel,driver/2017/12/15/tx2-rpi-camera-port.html
- 2. Jetson tx2 forums: https://devtalk.nvidia.com/member/3064655/
 - a. Check my posts and activity. (user rm95)
- 3. J90 technical_reference.pdf
- 4. Jetson_TX2_Series_Modules_DataSheet_v1.2.pdf